96COND Conductivity Transmitter

- Large LCD display
- Friendly interface
- Robust enclosure
- Easy to use menus
- Multiple mounting methods
- Two-Wire loop power



LECOL 96 series was designed with the user in mind.

Measurement information is easily read on the large liquid crystal display (LCD).


The graphic LCD screen can display multiple parameters simultaneously, including conductivity value, mA output signal, temperature, Ω -cm, and smart function keys.

96 series transmitter's keypad interface is user friendly. The smart function keys can be used to navigate to three submenus: "calibrate", "output", and " configure".

The "calibrate" submenu is for sensor and output signal calibration.

During calibration, output signals can be paused in "Output".

All measuring parameters can be set through "Configure".









Enclosure

The powder coated alloy housing meets NEMA 4X and IP65 requirements for use in harsh, industrial environments. The metal housing suppresses noise and prevents the interference caused by electromagnetic environment.

Mounting Methods

Pipe, wall, and panel mounting options are available to provide flexibility in different installation scenarios.




Calibration

Calibration is the process of adjusting the analyzer for accurate measurement. It can be conducted by two methods - comparison with a laboratory instrument or calibration of the sensor in a liquid standard.

Slope adjustments are easily made through a one point calibration using commonly available liquid conductivity standards.

The calibration mode of 96COND transmitter provides the ability to calibrate the sensor input, temperature input, and transmitter output. These functions, referred to as calibrate states, include Process Variable calibration, temperature calibration, edit calibration, reset calibration, and output calibration.



LECOL

Main screen displays

- 1. <u>Main display</u> Display of primary measurement
- 2. Minor display Additional measurements
- 3. <u>Function keys</u> Select submenus: Calibrate Output Configure
- 4. Current mode Mode in use
- 5. <u>Hold Output</u> Manual hold output at a specific value.



Specifications

Type Two-Wire conductivity transmitter Display 240*128 dots graphic LCD display Supply voltage 12~24 VDC, loop power Power consumption 0.6W Maximum Input range 0.01 cell : 0~ 200 uS/cm 0.1 cell: 0~2000 µS/cm 1.0 cell: 0~ 20000 µS/cm **Display resolution** 0.01 cell : 0.001 µS/cm 0.1 cell: 0.01 µS/cm 1.0 cell: µS/cm 0.1 Accuracy +/- 2% of F.S. +/- 1 °C Temperature compensation Manual. Automatic Temperature sensor types 3kΩ Balco / PT100 / PT1000 Analog output Isolated 4~20mA current output Configurable conductivity range μ S/cm, 0 ~ 2000 μ S/cm, 0~200 0 ~ 20000 µS/cm



Selection Keys

There are four selection keys under the screen – EXIT, SELECT, NEXT, MENU. Use the selection keys to:

- 1. EXIT: To quit, cancel the function
- 2. SELECT: To select measurement function
- 3. NEXT: To continue the setting process
- 4. MENU: To select different measurement modes: calibration mode, output mode, and configuration mode



Minimum	span		
0.01 c	ell :	1	µS/cm
0.1 c	ell :	10	µS/cm
1.0 c	ell :	100	µS/cm

```
Lower display
```

```
Temperature, resistivity, current output
Environmental
```

Operating temperature : -10 ~ 50 °C

- Storage temperature : -20 ~ 70 °C
- Operating humidity : 95% RH
- Storage humidity : 95% RH

Enclosure

NEMA 4X and IP65

Aluminum alloy with polyester powder coating Mounting

Panel, wall, pipe, and pipe mounting with weather shield

Certification

Low Voltage Directive 2014/35/EU

EN 61010-1:2010

Electromagnetic Compatibility Directive 2014/30/EU EN 61326-1:2013 CE marked

C F

Dimensions


Size : 144*144*177mm (H*W*D) Panel cut : 135*135(±0.2) mm Weight


2.2 kg


3 kg with pipe mounting kits

Mounting types


Panel mounting









Pipe mounting with weather shield



Dimensions



Electrical & sensor wiring



Ordering information

	o-Wire Conductivity Transmitter odel : 96 COND	(_)	(_)	(_)	(_)	(_)
Α	Programming options					
0	Basic	(A)				
1	Advanced					
В	Mounting type					
0	Panel mounting					
1	Wall mounting		(B)			
2	Pipe mounting					
3	Pipe mounting with weather shield					
С	Instruction manual					
0	Chinese (traditional)			(C)		
1	English					
D	Others				-	
0	None				(D)	
1	Cable glands				(D)	
2	S.S. electrical adaptor -1/2" NPT					
Ε	Identification Tag					
0	None					(E)
1	Stainless Steel					

*LECOL reserve the right to make technical changes or modify the contents of this document without prior notice.



Luh Cherng Enterprises co., Ltd.

No. 42, Mei-shan Rd., Niaosong Dist., Kaohsiung City 83346, Taiwan TEL : +886 7 7336377 FAX : +886 7 7336353 E-mail : sales@lecoltw.com Website : www.lecoltw.com

